



Macintosh Performa 630 Series

Macintosh Performa 630, 630CD, 631CD, 635CD,
636, 637CD, 638CD





Basics

Macintosh Performa 630 Series





General Information

The Macintosh Performa 630 Series computers are high-performance, low-cost modular computers with multimedia features, based on the Motorola 68LC040 microprocessor. The computers in this series are designed to accept a floppy drive, a hard drive, and an optional CD-ROM drive.

User Controls

User controls include

- Soft power-on control from keyboard
- Front panel sound-control push buttons
- Optional infrared remote control





Internal Expansion Connections

Four types of expansion slots on the logic board include

- DRAM SIMM expansion slot (1 or 2 slots)
- LC PDS slot
- Communications slot for modems and Ethernet found on LC 575
- Video-in slot for real-time video display, capture, and overlay

In addition to expansion slots on the logic board, there is an expansion ribbon connector for an optional TV tuner card. The TV-tuner connector provides NTSC and PAL input from an external TV antenna or cable.





IDE (Intelligent Device Electronics)

The internal hard drive in the Performa 630 Series computers uses IDE (Intelligent Device Electronics) technology, commonly used in DOS-compatible systems.

The internal IDE hard drive functions the same as a typical SCSI hard drive. You must replace IDE drives like for like.

The IDE drive does not affect SCSI ID selections or SCSI termination schemes. Seven external SCSI devices may be daisy-chained through the external SCSI port on the Performa 630 Series.





Plastic Panel Design

Performa 630 Series computers are designed for easy service. Plastic panels cover the metal bottom case, the metal top cover shield, and the left, right and rear sides of the metal case. You need to remove just one panel to reach either the logic board or drives.

Simply remove the front plastic panel (the drive bezel) to service all drives. Remove the plastic I/O door to slide out the logic board.





Product Configuration

Performa 630

Memory: 4 MB of RAM

Storage: Internal Apple 1.4 MB SuperDrive, Internal 250 MB IDE hard drive

Display: 14-inch Apple Performa Display Plus

Modem: Teleport send-fax/data modem





Performa 630CD

Memory: 8 MB of RAM

Storage: Internal Apple 1.4 MB SuperDrive, internal 250 MB IDE hard drive, internal AppleCD 300i Plus drive

Display: 14-inch Apple Performa Display Plus

Modem: Teleport send-fax/data modem





Performa 635CD

Memory: 5 MB of RAM

Storage: Internal Apple 1.4 MB SuperDrive, internal 250 MB IDE hard drive, internal AppleCD 300i Plus drive

Display: 15-inch Apple Performa Display

Modem: Teleport send-fax/data modem





Performa 636

Memory: 4 MB of RAM

Storage: Internal Apple 1.4 MB SuperDrive, internal 250 MB IDE hard drive

Display: 14-inch Apple Performa Display Plus

Modem: No modem included





Performa 637CD

Memory: 8 MB of RAM

Storage: Internal Apple 1.4 MB SuperDrive, internal 250 MB IDE hard drive, internal Apple CD 300i Plus drive

Display: 15-inch Apple Performa Display

Modem: Teleport send-fax/data modem

TV Tuner Card installed

Video-in Card installed





Performa 638CD

Memory: 8 MB of RAM

Storage: Internal Apple 1.4 MB SuperDrive, internal 250 MB IDE hard drive, internal Apple CD 300i Plus drive

Display: 15-inch Apple Performa Display

Modem: Teleport send-fax/data modem


TV Tuner Card installed

Video-in Card installed







Rear View Diagram





I/O Door Diagram






Logic Board Diagram

Note: Some logic boards may have only one DRAM SIMM slot. The maximum expandable DRAM is 36 MB on logic boards with either one or two SIMM slots.





Shield/Wiring Harness





Specifications

Macintosh Performa 630 Series





Processor

CPU

Motorola 68LC040 microprocessor
33 MHz

Addressing

32-bit internal registers
32-bit address bus
32-bit data bus





Memory

DRAM	4 MB built in Expandable to 36 MB (72-pin, 80 ns or faster SIMMs) Note: See Basics chapter, “Product Configurations,” for specific model configurations.
DRAM Frame Buffer	1 MB
ROM	1 MB
VRAM	Video data are stored in the 1 MB DRAM frame buffer. The Performa 630 Series does not support video memory expansion.





Disk Storage

Floppy Drive

1.4 MB Apple SuperDrive Manual Insert

CD-ROM Drive

Optional Apple 300i Plus CD-ROM drive

Hard Drive

250 MB IDE hard drive

Note: Performa 630 Series computers do not support internal SCSI hard drives.





I/O Interfaces

Serial	Two RS-232/422 serial ports; mini DIN-8 connectors
SCSI	One external SCSI port; DB-25 connector Supports up to six external SCSI devices
Apple Desktop Bus	One Apple Desktop Bus (ADB) port; mini DIN-4 connector
Video	One DB-15 monitor port on built-in video daughterboard





Sound	<p>Mono sound input port supports external microphone or line-level inputs.</p> <p>Bias current for electret microphone</p> <p>Stereo sound output jacks at front and rear of the computer</p>
Processor-Direct Slot	<p>One 114-pin internal expansion slot for LC-compatible processor-direct card</p>
Communications Slot	<p>One 112-pin internal expansion slot for modem and Ethernet</p>
Video-in Slot	<p>One 60-pin internal video-in slot for real-time video display, capture, and overlay</p>
TV Tuner	<p>One 10-pin port for TV tuner card</p>





Controls

Softpower control from keyboard

Front panel push button control for sound volume

Front panel stereo headphone jack

Optional infrared remote control





I/O Devices

Keyboard

Apple Extended Keyboard II (other ADB keyboards supported)

Mouse

ADB Mouse II

Microphone

Electret, omnidirectional
Operates on 8 VDC supplied by microphone port on CPU





Sound and Video

Sound

8-bit monophonic sound input

8-bit stereo sound output (16-bit in CD mode), level nominally
0.5 V RMS into 39 ohms

Internal speaker muted when a plug is inserted into an output jack

Video

Supports all Apple 12-inch, 13-inch, and 14-inch monitors,
Apple 15-inch multiple synchronous monitor, and VGA (640 x
480) monitors at maximum 16-bit per pixel

Supports Apple 16-inch and SVGA (800 x 600) monitors at
maximum 8-bit per pixel





Electrical

Line Voltage

100-240 VAC

Frequency

50-60 Hz

Maximum Power

5 W, not including monitor





Physical

Dimensions

Height: 4.3 in. (10.95 cm)

Width: 16.5 in. (41.95 cm)

Depth: 12.6 in. (32 cm)

Weight

Without CD-ROM: 17 lb. (7.7 kg)

With CD-ROM: 19 lb. (8.6 kg)

Weight varies with options





Troubleshooting

Macintosh Performa 630 Series





General

The Symptom Charts included in this chapter will help you diagnose specific symptoms related to your product. Because cures are listed on the charts in the order of most likely solution, try the first cure first. Verify whether or not the product continues to exhibit the symptom. If the symptom persists, try the next cure. (Note: If you have replaced a module, reinstall the original module before you proceed to the next cure.)

If you are not sure what the problem is, or if the Symptom Charts do not resolve the problem, refer to the Flowchart for the product family.

For additional assistance, contact Apple Technical Support.





Symptom Charts

Error Chords

Eight-tone error chord sounds during startup

- 1 Reseat SIMMs
- 2 Replace SIMMs. Refer to Hardware/Memory manual.
- 3 Replace logic board. Retain customer's SIMMs.
- 4 Perform SIMM verification on replacement logic board.

Four-tone error chord sounds during startup

- 1 Disconnect hard drive power cable and reboot system. If startup sequence is normal, run "Macintosh Hard Disk Test" and replace hard drive if necessary.
- 2 Disconnect floppy drive cable and reboot system. If startup sequence is normal, replace floppy drive.
- 3 Replace logic board. Retain customer's SIMMs.





System

Flashing “?” appears at startup in system with vacant PDS and communication slots

- 1 Diagnose hard drive with Disk First Aid included on Power Macintosh CD-ROM.
- 2 Perform repairs and then go to step 4.
- 3 If repairs are impossible, back up drive, reformat with Drive Setup 1.0.3, and then go to step 4.
- 4 Update driver using Drive Setup 1.0.3.
- 5 Perform clean install

Menu bar constantly flashes or system constantly beeps

- 1 Verify that front panel control buttons are not jammed.
- 2 Reseat drive bezel and front panel control board.





Audio

Crackling noise is present when you play sounds other than system beeps and you are not in “play through” mode

- 1 If static noise varies when you adjust volume by Sound control panel, use Audio Volume Extension 1.1 or later. Note: Audio Volume Extension is available from standard Apple software update sites.
- 2 Replace logic board.

Sound distortion with MPEG board installed

Replace MPEG board with modified MPEG board. A modified board should have a jumper present from U5 Pin 2 to D1 Pin 1.





Video

Screen is dark, audio and at least one drive operate, fan runs, and LED is lit

- 1 Confirm that video connections are secure.
- 2 Confirm that monitor-out daughterboard connection on the fan bracket is secure.
- 3 Reseat logic board.
- 4 Perform monitor adjustments
- 5 Replace monitor.
- 6 Replace logic board. Retain customer's SIMMs.
- 7 Replace power supply.

Screen is dark, audio and drive do not operate, but fan runs and LED is lit

- 1 Reseat logic board.
- 2 Remove expansion card, if present.
- 3 Remove peripherals.
- 4 Replace SIMMs. Refer to Hardware/Memory manual.
- 5 Replace logic board. Retain customer's SIMMs.
- 6 Replace power supply.





Video (Continued)

Partial or whole screen is bright and audio is present, but no video information is visible

- 1 Reseat logic board.
- 2 Replace fan/video card bracket.
- 3 Replace monitor.
- 4 Replace logic board. Retain customer's SIMMs.

Video will not play or system hangs when you attempt to run video in units with MPEG card

- 1 If chip at location U12 on MPEG card displays number 341S0205, check all connections.
- 2 If chip at location U12 on MPEG card does not display number 341S0205, replace MPEG card





Video (Continued)

Screen is completely dark, fan is not running and LED is not lit

- 1 Check all external power connections.
- 2 Computer powers on exclusively through softpower on keyboard. Verify that power-on connections of keyboard are functioning by testing with known-good keyboard.
- 3 Reseat logic board.
- 4 Unplug 5.4 battery, wait 20 seconds, plug in battery, and restart computer.
- 5 Verify that monitor has power.
- 6 Remove expansion card, if present.
- 7 Remove peripherals.
- 8 Replace power supply.
- 9 Replace logic board. Retain customer's SIMMs.





Video (Continued)

Vertical lines, horizontal lines, or snow appears on screen, or screen is completely dark; startup tone is normal

- 1 Perform monitor adjustments.
- 2 Replace monitor.
- 3 Replace logic board. Retain customer's SIMMs.
- 4 Replace power supply.

Unable to tune in some UHF channels.

Replace video-in card Rev. A, part number 661-0159, with video-in card Rev. B, part number 661-1073.





Floppy Drive

Audio and video are present, but internal drive does not operate

- 1 Reseat logic board.
- 2 Replace floppy drive.
- 3 Replace shield/wiring harness.
- 4 Replace logic board. Retain customer's SIMMs.

Disk ejects; display shows Mac icon with blinking "X"

- 1 Replace disk with known-good system disk.
- 2 Replace floppy drive cable.
- 3 Replace floppy drive.
- 4 Replace logic board. Retain customer's SIMMs.





Floppy Drive (Continued)

Disk does not eject

- 1 Switch off system and hold mouse button down while switching system back on.
- 2 Eject disk manually by pushing opened paper clip into hole beside drive slot.
- 3 Replace floppy drive cable.
- 4 Replace floppy drive.

Drive attempts to eject disk, but doesn't

- 1 Switch off system and hold mouse button down while switching system back on.
- 2 Eject disk manually by pushing opened paper clip into hole beside drive slot.
- 3 Replace floppy drive cable.
- 4 Replace floppy drive.





Hard Drive

Internal hard drive runs continuously

- 1 Make sure System is version 7.1.2P (or later).
- 2 Replace hard drive cable.
- 3 Replace internal hard drive.
- 4 Replace logic board. Retain customer's SIMMs.

Internal hard drive does not operate

- 1 Confirm that all hard drive connections are secure.
- 2 Reseat logic board.
- 3 Replace internal IDE hard drive.
- 4 Replace shield/wiring harness chassis.
- 5 Replace logic board. Retain customer's SIMMs

Hard drive not found when booted from CD-ROM drive

Use Drive Setup 1.03.





CD-ROM Drive

CD-ROM drive does not accept disc

- 1 Replace disc (if dirty or damaged).
- 2 Reseat CD-ROM drive.
- 3 Replace CD-ROM drive.

Volume control does not operate correctly

- 1 Check Control Panel Sound setting.
- 2 Check front panel controls.
- 3 Reseat front panel control board.
- 4 Replace shield/wiring harness chassis.

Macintosh cannot mount CD-ROM drive

- 1 Reseat CD-ROM drive.
- 2 Check SCSI ID setting; internal CD-ROM drive was originally set at 3 at the factory.
- 3 Replace CD-ROM drive.





Peripheral

Works with internal or external SCSI device but does not work with both

- 1 Verify that SCSI select switch on external device is set to different priority from internal CD-ROM drive.
- 2 Verify that both ends of external SCSI device are terminated.
- 3 Replace terminator on external device.
- 4 Verify that terminator is installed on internal SCSI drive.
- 5 Replace SCSI select cable (on external SCSI device).

Cursor does not move

- 1 Reboot system.
- 2 Check mouse connection.
- 3 If mouse was connected to keyboard, connect mouse to rear ADB port and disconnect keyboard. If mouse works, replace keyboard.
- 4 If mouse does not work in ADB port, replace mouse.
- 5 Reseat logic board.
- 6 Replace logic board. Retain customer's SIMMs.





Peripheral (Continued)

Cursor moves, but clicking mouse button has no effect

- 1 Replace mouse.
- 2 Reseat logic board.
- 3 Replace logic board. Retain customer's SIMMs.

Double-click doesn't open application, disk, or server

- 1 Remove extra system files on hard drive.
- 2 Check mouse speed on Control Panel.
- 3 Unplug 5.4 battery, wait 20 seconds, plug in battery, and restart computer.
- 4 If mouse was connected to keyboard, connect mouse to rear ADB port and disconnect keyboard. If mouse works, replace keyboard.
- 5 If mouse does not work in ADB port, replace mouse.
- 6 Replace logic board. Retain customer's SIMMs.





Peripheral (Continued)

No response to any key on keyboard

- 1 Make sure System is version 7.1.2P (or later).
- 2 Check keyboard connection to ADB port.
- 3 Replace keyboard.
- 4 Reseat logic board.
- 5 Replace logic board. Retain customer's SIMMs.

Known-good ImageWriter or ImageWriter II does not print

- 1 Make sure that Chooser and Control Panel settings are correct.
- 2 Make sure System is version 7.1.2P (or later).
- 3 Check printer DIP switches.
- 4 Replace printer interface cable.
- 5 Replace logic board. Retain customer's SIMMs.





Peripheral (Continued)

Known-good
LaserWriter does not
print

- 1 Make sure that Chooser and Control Panel settings are correct.
- 2 Make sure System is version 7.1.2P (or later).
- 3 Refer to Networks and Communications manual.





Miscellaneous

Rattling sound at startup in system with Apple External Video Connector

Press or fold Apple External Video cable to prevent it from contacting fan blades

.





Take Apart

Macintosh Performa 630 Series







Drive Bezel

No preliminary steps are required before you begin this procedure.

- 1 Locate the two latches below the ridge on the drive bezel.





- 2 **Caution:** When using a screwdriver to release a latch, press up carefully. Do not scratch or gouge the plastic.


Insert a flat-blade screwdriver at each latch.

- 3 Pry up to release each latch.





- 4 Swing up the drive bezel and pull it away from the metal chassis.



Drive Bezel







Front Panel Control

Before you begin, remove the drive bezel.


Caution: Review the ESD precautions in Bulletins/ Safety.





- 1 Insert a flat-blade screwdriver about an inch between the side panel and the front panel control.
- 2 Pry open the latch to release the front panel control.






- 3 Pull the front panel control out just far enough to reach the ribbon cable connector.

Replacement Caution:
When you replace the front panel control assembly, make sure that the headphone jack is at the bottom of the assembly.





- 4 Disconnect the front panel control from the ribbon cable.

Replacement Note: Take care not to crimp the cable when you replace the front panel control.






Drive Security Bracket


Before you begin, remove the drive bezel.

Caution: Review the ESD precautions in Bulletins/ Safety.



Drive Security Bracket





Remove the mounting screw and pull off the drive security bracket.

Replacement Note: Be sure to correctly position the four tabs of the drive security bracket.







Floppy Drive

Before you begin, remove the following:

- Drive bezel
- Drive security bracket

Caution: Review the ESD precautions in Bulletins/Safety.






- 1 Lift the front of the floppy drive and carrier.
- 2 Pull the floppy drive out just far enough to reach the ribbon cable connector.

Replacement Note:
When you replace the floppy drive, make sure that the tab of the floppy carrier is seated properly in the floppy drive guide.





- 3 Disconnect the floppy drive from the floppy drive cable.

Replacement Note: If you are replacing a defective floppy drive, invert the drive and carrier and remove the four carrier mounting screws. Separate the drive from the carrier.






CD-ROM Drive

Before you begin, remove the following:


- Drive bezel
- Drive security bracket

Caution: Review the ESD precautions in Bulletins/Safety.



CD-ROM Drive






- 1 **Note:** To perform this step, you may want to insert a screwdriver in the slot of the release latch to help you pull the CD-ROM drive.

Push up the release latch and pull the CD-ROM drive from the chassis.

Note: You may need to use some initial force to disconnect the CD-ROM from the internal wiring harness.





Note: Perform the following steps only if you are replacing a defective CD-ROM drive.

- 2 Disconnect the CD-ROM audio adapter from the drive.
- 3 Disconnect the SCSI adapter.
- 4 Remove the four mounting screws and carrier from the CD-ROM drive.





Replacement Caution:

Before replacing the SCSI adapter, make sure that the SCSI drive connector pins are not bent.






Hard Drive

Before you begin, remove the following:

- Drive bezel
- Security bracket


Caution: Review the ESD precautions in Bulletins/Safety.

Note: Performa 630 computers do not support internal SCSI hard drives. Refer to Basics for more information on the IDE hard drive interface.



Hard Drive






- 1 Using the pull tabs, disconnect the IDE data cable from the hard drive connector.
- 2 Disconnect the power cable.





- 3 Using a flat-blade screwdriver, push up the release latch and pull the IDE hard drive from the chassis.






I/O Door

No preliminary steps are required before you begin this procedure.

Caution: Review the ESD precautions in Bulletins/ Safety.





I/O Door





- 1 Push down the two locking tabs and swing down the door.





Replacement Note:

Carefully align the three hinge tabs before swinging up the I/O door.






Logic Board

Before you begin, remove the I/O door


Caution: Review the ESD precautions in Bulletins/ Safety.

Note: If you are replacing a logic board that has one SIMM slot, replace it with P/N 661-0158. If you are replacing a logic board that has two SIMM slots, replace it with P/N 661-1114.



Logic Board with Fence






- 1 Remove the two screws from the metal fence.
- 2 **Note:** The logic-board-and-fence assembly may need a firm initial tug to loosen it from the shield/wiring harness.

Slide out the logic-board-and-fence-assembly.





Note: Perform the following steps only if you are replacing a defective logic board.


- 3 Remove the two Phillips screws that secure the fence to the solder side of the logic board.
- 4 Using a T9 torx driver, remove the two torx screws that secure the logic board fence to the SCSI connector.
- 5 Separate the logic board fence from the logic board.






Rear Panel

No preliminary steps are required before you begin this procedure.






- 1 Remove the two Phillips screws.
- 2 Lift off the rear panel.





Replacement Note:

Carefully align the flat tab and the four hinge tabs.






Top Cover


Before you begin, remove the following:

- Drive bezel
- Rear panel

Caution: Review the ESD precautions in Bulletins/Safety.


Note: The top cover consists of two parts that must be removed separately—a plastic cover on top of a metal shield.






- 1 Insert a small flat-blade screwdriver into the cutout and lift the front edge to clear the plastic stops.
- 2 With your other hand, slide the plastic cover forward about one-half inch.
- 3 Lift the plastic cover off the metal shield.





- 4 Remove the two Phillips screws.
- 5 Slide the metal shield toward the front of the unit about one-half inch.





- 6 Lift the front edge of the metal shield about an inch.
- 7 Under the metal shield, squeeze together the ends of the floppy drive cable security wire and unhook it from the metal shield.
- 8 Remove the security wire from the floppy drive cable.
- 9 Lift off the metal shield.







Shield/Wiring Harness

Before you begin, remove the following:

- Drive bezel
- Drive security bracket
- Front panel control
- Floppy drive
- CD-ROM drive
- Hard drive
- I/O door
- Logic board
- Rear panel
- Top cover and shield






Plastic Side Panel

Caution: Review the ESD precautions in Bulletins/ Safety.

- 1 Push in and slide the plastic side panels toward the front of the computer about one-half inch.
- 2 Remove the plastic side panels.






- 3 **Note:** This graphic shows the bottom case tipped to provide a better view of the screw. Perform this procedure with the bottom case seated on a firm, flat surface.

Remove the screw that secures the shield/wiring harness to the bottom case.






2-Pin Speaker Cable




- 4 Disconnect:
 - 2-pin speaker cable
 - 34-pin monitor-out cable
 - 10-pin tuner cable, if connected
- 5 Slide the tuner cable from the cable holder.





- 6 Release the latch on the 14-pin power supply cable and disconnect the cable.
- 7 Disconnect the 2-pin fan cable.
- 8 Disconnect the 6-pin header-to-power-supply cable and remove the cable from the routing notch in the power supply case.





- 9 Lift up one side of the shield/wiring harness a few inches, then lift up the other side about an inch.
- 10 **Note:** Guide the speaker cable through the shield/wiring harness as you remove the harness.


Remove the shield/wiring harness.






Replacement Note: In rerouting the cables, do not crimp cables between the harness and the floor or sides of the bottom case. Route the speaker cable between the logic board connector and the CD-ROM shelf. Route the fan, power supply, and header cables to the side of the front panel control bay.





Replacement Note: Arrange the cables as shown before replacing the shield/wiring harness. When dressing the cables, do not crimp them between the harness and the floor of the bottom case, or between the harness and the sides of the bottom case. Route the speaker cable between the logic board connector and the CD-ROM shelf. Route front panel control, power supply, and header cables to the side of the front panel control bay.






Replacement Note:

Carefully position all six tabs of the shield/wiring harness.





Fan/Video Card Bracket



Fan/Video Card Bracket

Before you begin, remove the following:


- Drive bezel
- I/O door
- Top cover and shield

Caution: Review the ESD precautions in Bulletins/ Safety.






- 1 Remove the two screws from the logic board metal fence.





2-Pin Speaker Cable




- 2 Disconnect:
 - 2-pin speaker cable
 - 34-pin monitor-out cable
 - 10-pin tuner cable, if connected
- 3 Slide the tuner cable from the cable holder.






- 4 Disconnect the 2-pin fan cable.





Fan/Video Card Bracket



- 5 Lift up one side of the fan/video card bracket, then the other.
- 6 Remove the fan/video card bracket.







Speaker

Before you begin, remove the following:

- Drive bezel
- Drive security bracket
- Front panel control
- Floppy drive
- CD-ROM drive
- Hard drive
- I/O door
- Logic board
- Top cover and shield
- Shield/wiring harness
- Fan/video card bracket





Pull up on the speaker to disengage it from its hook-and-loop connection.






Power Supply


Before you begin, remove the following:

- Drive bezel
- Drive security bracket
- Front panel control
- Floppy drive
- CD-ROM drive
- Hard drive
- I/O door
- Logic board
- Top cover and shield
- Shield/wiring harness
- Fan/video card bracket





Power Supply



Remove the screw from the power supply and lift the power supply from the bottom case.






Bottom Case

To remove the bottom case, remove the following:

- Drive bezel
- Drive security bracket
- Front panel control
- Floppy drive
- CD-ROM drive
- Hard drive
- I/O door
- Logic board
- Top cover and shield
- Shield/wiring harness
- Fan/video card bracket
- Speaker
- Power supply





Upgrades

Macintosh Performa 630 Series






Processor Upgrade


Before you begin, remove the following:

- I/O door
- Logic board
- Card in PDS slot (if any)

Caution: Review the ESD precautions in Bulletins/ Safety.

The Macintosh Processor Upgrade kit allows 68LC040 computers to switch between a PowerPC 601 processor and a 68LC040 processor.





The upgrade board includes the PowerPC 601 processor on board and a socket to accept the customer's 68LC040 processor.

Refer to the Macintosh Processor Upgrade manual for information about specifications and troubleshooting.

Note: The Macintosh Processor Upgrade comes packaged with the Macintosh Processor Upgrade board, 256K cache card, 040 heat sink, and hook-and-loop





fasteners. If you need to order service replacement parts, order the parts separately.

Note: To install the upgrade, you will need a processor removal tool. Order the removal tool as a separate service part.

Note: The cache card comes installed on the upgrade board.





Installation Procedure Overview

There are four basic steps to installing the Macintosh Processor Upgrade.

- Remove the 68LC040 processor from the customer's logic board
- Install the 68LC040 processor on the upgrade board
- Prepare the upgrade and logic boards for installation
- Install the upgrade board on the logic board







Detailed procedures for this computer follow.

Remove the 68LC040 Processor from the Logic Board

- 1 Locate the 68LC040 processor on the logic board.





Note: This graphic shows the proper way to remove any 68LC040 chip from its logic board. Your logic board may differ somewhat from this graphic.

- 2 Position the teeth of the processor removal tool in the groove between the processor and the logic board socket.

Caution: Be sure to lift up on the handle of the processor removal tool. Pressing down could damage components on the logic board.





- 3 **Caution:** Pry up each side of the processor only slightly to avoid bending the pins.


Gently lift up the processor removal tool handle and pry up each side of the processor from the socket.

- 4 Remove the processor.






Install the 68LC040 Processor on the Upgrade Board



- 1 **Note:** The alignment corner of the 68LC040 processor is missing one pin.
The alignment corner of the spacer is missing a pin hole.
- 2 Position the spacer alignment corner over the 68LC040 processor alignment corner
- 3 Place the spacer on the processor.





- 4 **Caution:** Forcing the 68LC040 processor connector pins into the socket could damage the pins. If the processor resists installation, check the pin alignment.

Caution: Place the upgrade board on a firm even surface to avoid bending the upgrade board when pressing the processor into the socket.





Caution: Use two thumbs to evenly distribute the pressure as you press the processor into the socket.


Hold the processor and spacer together and position the spacer alignment corner over the upgrade socket alignment corner.

- 5 Press the processor connector pins into the socket until you hear a “snap.”





Note: On a correctly installed 040 processor, a very small gap separates the 040 chip from the metal spacer. A larger gap caused by the barrel sockets of the upgrade board separates the upgrade board and the spacer.






Prepare the Upgrade and Logic Boards for Installation

Note: The following steps explain how to prepare the logic board to accept the upgrade board.

Caution: The EMI clips on the bottom of the logic board are fragile. Do not apply heavy pressure directly to these clips or you may bend the logic board.






- 1 Place a piece of antistatic foam directly under the processor socket on the bottom side of the logic board.


Note: This step helps prevent the logic board from bending when you apply pressure in the next few steps.





- 2 Lift and rotate the battery one quarter turn from its original position on the logic board. (This step makes room for the upgrade board.)
- 3 Press the battery firmly into its new position.





Install the Upgrade Board

- 1 **Caution:** Forcing the upgrade board connector pins into the logic board socket could damage the pins. If the connector resists installation, check the pin alignment.

Position the upgrade connector alignment corner over the logic board socket alignment corner.





- 2 Carefully align the pins along all sides of the processor and socket.
- 3 Firmly press the connector pins into the logic board socket.

Note: To install the software, refer to the upgrade Owner's Guide.






Logic Board and Upgrade Board Returns

Return the upgrade and logic boards to their original conditions before sending them to Apple. Be sure to remove the upgrade board from the logic board and reinstall the 68LC040 processor on the logic board.

Replacement Caution: To avoid bending any pins when removing the 68LC040 processor, pry up each side only slightly.





Power Macintosh 5300/6300 Logic Board Upgrade

Before you begin, remove the following:

- I/O door
- Logic board
- Card in PDS slot (if any)

.Caution: Use a grounded workbench and always wear a grounding wriststrap.

The Power Macintosh 5300/6300 Logic Board Upgrade is a finished goods product.






The upgrade kit includes the 603e, 100 MHz logic board and logic board fence. See Take Apart chapter, Logic Board topic for installation procedures.

Service Provider's Checklist

- Install the upgrade board
- Run Safe Install
- Install System 7.5
- Turn on the upgrade board
- Turn on Modern Memory Manager
- Restart the computer to verify the board works properly

Replacement Note: You may need to remove the 603e processor on the 6300 series logic board to install or service SIMMs. See “6300 SIMM Upgrade.”






Exploded View

Macintosh Performa 630 Series





Exploded View



Product family configurations may vary. For number of part with asterisk, see parts list.

