

## CCS-7710: Cable for Daisywriter (1/97)

Article Created: 11 July 1985 Article Reviewed/Updated: 28 January 1997
TOPIC
Listed below are the cable pinouts for connecting the CCS-7710 interface card to the Daisywriter printer.
DISCUSSION
CCS-7710 DAISYWRITER (50 pin connector)
3 <> 3 7 <> 6 4 <> 49
CCS-7710 dip switch settings
All on except #1
Daisywriter dip switch settings
TOP BANK: all off execpt #1 CENTER BANK: all off except #8, BOTTOM BANK: all off except #2
* This cable is for use with the Apple IIe.
Article Change History: 28 Jan 1997 - Reviewed for technical accuracy, revised formatting.
Copyright 1985-97, Apple Computer, Inc.
Keywords: <none></none>

\_\_\_\_\_\_

This information is from the Apple Technical Information Library.

ArticleID: TECHINFO-0001474

19970129 10:07:13.00

Tech Info Library Article Number: 1474