



Tech Info Library

Monitor III: Repair Tips

This article last reviewed: 7 November 1988

A typical problem reported on the Monitor III is "no video". In these cases, adjusting either the contrast or brightness controls on the monitor solves the problem. With an Apple II or II+, the problem lies in the computer's video adjustment potentiometer, K14 on the main logic board. It is often adjusted too low.

Before you send a Monitor III in for exchange, make sure that the monitor has the problem and not:

1. the video cable or
2. too low of an adjustment of the video signal by the video adjustment potentiometer, K14 on the main logic board.

Copyright 1988 Apple Computer, Inc.

Keywords: <None>

=====
This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 155