



# Tech Info Library

## IIC Monitors **PROBLEM/CURE: Intermittent Flashing Screen**

This article last reviewed: 29 April 1988

**PROBLEM DESCRIPTION:** Video display intermittently appears and disappears.

**CAUSE:** RCA connectors on either end of the video cable from the monitor to the computer may not be making good contact.

**CURE:** Slightly crimp (squeeze with a pair of pliers) the shield part of the RCA connector on the video cable on both ends so that it makes slightly tighter fit on the monitor and the computer.  
(DO NOT OVERCRIMP; it must be snug only).

If this cure does not resolve the problem, go to the Tech Procedures to obtain a General Troubleshooting procedure.

Copyright 1988 Apple Computer, Inc.

Keywords: hts

=====  
This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 1593