



Tech Info Library

Monitor II PROBLEM/CURE: Picture Rolling

This article last reviewed: 29 April 1988

PROBLEM DESCRIPTION: After the Monitor II has had a chance to warm up, the picture just won't stop rolling.

WARNING: Remember to turn off the Monitor II and unplug it whenever the case is removed for the procedure below.

CAUSE: 1. Vertical Hold misadjusted
2. Bad electronics module

CURE: 1. Adjust the Vertical Hold (set must be turned on and operating for this adjustment).
2. If Vertical Hold doesn't fix the problem, replace the electronics module.

If the above cure doesn't solve your problem refer to the Tech Procedures to obtain the general troubleshooting procedure for this product.

Copyright 1988, Apple Computer, Inc.

Keywords: hts

=====
This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 1608