



Tech Info Library

AppleColor High-Resolution RGB: Degauss adjustments

The Degauss switch corrects small patches of color distortion that can occur on the screen. You should press the Degauss switch if, for example, you notice that a small area in an all-red field of the screen seems to be slightly off color, say, with blue. This situation is more likely if you've left the monitor on for a long time or if you moved the monitor while the power was on.

The switch is located just below the On-Off button on the back panel. Pressing the Degauss switch makes the screen flicker for a few seconds as the monitor corrects the colors in your display. When the image steadies, the colors should be correct.

<None>

Keywords: <None>

=====
This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 2168