



Tech Info Library

ImageWriter II Print Quality Problems

This article last reviewed: 2 November 1988

YOU WILL NEED:

1. Level I Tech Procedures for ImageWriter II
2. ImageWriter II User's Manual

BEFORE YOU START:

1. If a replacement module/part doesn't fix the problem, reinstall the original module/part before continuing with the procedure.
2. For location of IW II module/parts or adjustment procedures, refer to the Level I Tech Procedures.

INSTRUCTIONS:

1. Check the paper guide positioning adjustment.
2. Turn off the printer and replace the flexible cable.
3. Check the print head as follows. If it proves defective, replace it.
 - 3.1 Set the digital multimeter to measure 200 ohms resistance.
 - 3.2 Remove the print head and place it PCB side down with the edge connectors facing you. Place one probe on each side of the first edge finger on the right side of the print head. The resistance value should be approximately 3 ohms.
4. Replace the Drive PCB.
5. Replace the Main CPU PCB.

Copyright 1988 Apple Computer, Inc.

Keywords: hts

=====
This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 1409