



# Tech Info Library

## Performa: Deleting Items from the Directory (7/93)

Article Created: 19 July 1993

TOPIC -----

How do I delete items from the directory on my Performa 450? I dragged them to the Trash and emptied the Trash, but they keep showing up.

DISCUSSION -----

Depending on where they show up, this may be normal. If you use At Ease, going to the Finder to delete an item will not delete it from At Ease. If you go back into At Ease, the icon for the item is still on one of the panels. However, if you click on the icon, a dialog box appears explaining that the original item couldn't be found. The item will be removed from the At Ease panel.

If the item is in the Launcher window, you will need to go into the Launcher items folder located in the System folder and remove the alias for the item.  
Copyright 1993, Apple Computer, Inc

Keywords: <None>

=====  
This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 12655