



Tech Info Library

Power Macintosh 5400: Switching to Ethernet (9/96)

Article Created: 31 May 1996

Article Reviewed/Updated: 20 September 1996

TOPIC -----

I have a Power Macintosh 5400/120 computer which comes with the Apple CS II Ethernet card pre-installed. Using the Network Software Selector, I have switched from Open Transport to Classic AppleTalk. However, the Network control panel does not have an option to switch to EtherTalk. I checked the Extensions folder and the Apple Ethernet CS II extension is installed. How do I switch to EtherTalk?

DISCUSSION -----

The Apple Ethernet CS II card and software only function under Open Transport. Under Classic AppleTalk, the Power Macintosh 5400/120 and Power Macintosh 6400 computers cannot switch to Ethertalk. To connect to an Ethernet network using the Apple Ethernet CS II card and the Power Macintosh 5400/120 or Power Macintosh 6400, you must switch to Open Transport, restart the computer, and then use the AppleTalk control panel to switch to Ethernet.

This article was published in the Information Alley on 3 June 1996.

Article Change History:

20 Sep 1996 - Added Power Macintosh 6400 to discussion.

27 Jun 1996 - Added keyword.

03 Jun 1996 - Corrected typo.

Copyright 1996, Apple Computer, Inc.

Keywords: supt,kppc,hts,kalley

=====

This information is from the Apple Technical Information Library.

19960923 07:56:00.00

Tech Info Library Article Number: 19921