



Tech Info Library

Power Macintosh 7100: Audio Connector Pinouts (4/95)

Article Created: 27 April 1995

TOPIC -----

I need to build a cable to make a non-Apple CD ROM audio work on the Power Macintosh 7100. I cannot find the pinouts for the audio connector on the logic board anywhere.

DISCUSSION -----

The pinouts for the CD-ROM Audio Connection on the Power Macintosh 7100 is:

Pin	Signal
1	CD in Left
2	CD Common
3	CD Common
4	CD in Right

The connector is J19 on the logic board. This connector is located behind the drive bays.

Support Information Services
Copyright 1995, Apple Computer, Inc.

Keywords: KPPC

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 17655