



Tech Info Library

QuickDraw GX: Printing To Non-GX Supported Device (2/95)

Article Created: 02 August 1994

Article Reviewed/Updated: 14 February 1995

TOPIC -----

How do I print to an output device that does not currently have a QuickDraw GX compatible print driver?

DISCUSSION -----

If you have a non-GX driver, you can disable QuickDraw GX via the extension manager and restart. This will let you print using the original driver.

The only other alternative is to check with the vendor of the output device to see if they are planning a GX-compatible driver.

Article Change History:

14 Feb 1995 - Reviewed for technical accuracy.

Support Information Services

Copyright 1994-95, Apple Computer, Inc

Keywords: sys75

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 15952