



# Tech Info Library

## System 7: When LaserWriter Driver Doesn't Appear in Chooser

Article Created: 5 August 1991

### Article Change History

-----

09/11/92 - REVISED

- With more information.

### TOPIC -----

I can't select the LaserWriter icon in the Chooser. What's the problem?

### DISCUSSION -----

You probably have a damaged driver. Only the LaserWriter (PostScript) driver is affected. To fix this, reinstall the driver. Make sure you reinstall the correct version, from your original disks.

Copyright 1991, 1992, Apple Computer, Inc.

Keywords: Sys7

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 7992