

Macintosh: Erasing Parameter RAM

Just as Preferences in the Lisa keeps the settings, the Parameter Memory chip or Parameter RAM in the Macintosh maintains system information: Clock, date, and alarm settings, some Control Panel settings, and Serial port configurations.

If necessary, Parameter RAM may be erased entirely:

- 1. Turn off the Macintosh
- 2. Unplug the Macintosh
- 3. Remove the battery (do not try to draw off charge by placing the battery back in upside down)
- 4. After at least 10 minutes, reinsert battery
 <None>

Keywords: <None>

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 1717