



Tech Info Library

PowerBook: Use VersaTerm 4.6 and VersaTerm-PRO 3.6

Article Created: 10 July 1992

TOPIC -----

I'm using VersaTerm by Synergy Software on my Macintosh PowerBook 170. When I press the Enter key, nothing happens. The Enter key works fine with other applications like Microsoft Word and Microsoft Excel. Also, if I connect an Apple Extended Keyboard to the PowerBook, the Enter key on this keyboard works correctly.

DISCUSSION -----

On the Apple Extended Keyboard, the Enter key has a virtual key code of \$4C; on the PowerBook keyboard, the Enter key has a virtual key code of \$34. Both, however, generate ASCII code \$03.

Synergy technical support said that you need to use VersaTerm 4.6 and VersaTerm-PRO 3.6 with the PowerBook computers. Contact Synergy Software directly for upgrade information.

To locate a vendor's address and phone numbers, use the vendor name as a search string.

Article Change History

11/03/92 - Corrected the vendor search string information

Support Information Services

Copyright 1992, Apple Computer, Inc.

Keywords: KCOMPAT,kpbook

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 10435