



# Tech Info Library

## Macintosh SE: SuperDrive and Accelerator Cards Anomaly (11/94)

Article Created: 4 March 1990

Article Reviewed/Updated: 14 November 1994

\* RESTRICTED: Apple Internal and Support Providers Only \*  
Not For General Public Release

TOPIC -----

I have experienced problems installing the Apple SuperDrive (formerly Apple FDHD) in Macintosh SEs that have accelerator cards.

In a system using the Radius Accelerator and a SuperDrive, if I insert an initialized high-density disk, the Macintosh says that the disk is uninitialized. When I click OK to initialize, it fails.

After installing the SuperDrive in a system using SuperMac Prodigy SE, the Macintosh bombs every time I insert a high-density disk. The hard disk starts up OK. If I remove the Prodigy SE, everything works fine.

Are these problems related to the accelerator cards or the SuperDrive?

DISCUSSION -----

Both SuperMac and Radius are aware of the problems you describe and are working on solutions. For more details, search the Tech Info library under "SuperMac" and "Radius".

Article Change History:

14 Nov 1994 - Reviewed for technical accuracy.

Support Information Services

Copyright 1990-94, Apple Computer, Inc.

Keywords: hts

=====  
This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 5145