



# Tech Info Library

## ImageWriter II: When It Suddenly Starts Printing in Hex

This article last reviewed: 11 September 1987

It can be distressing when your ImageWriter II unexpectedly prints a hexadecimal code dump. Hex printing is actually a feature of the ImageWriter II that can be very helpful for programmers.

Hex printing occurs when the Select button is pressed when the ImageWriter II is turned on. This can easily happen accidentally, because the Select button is so close to the power switch. If this happens:

1. Turn power off.
2. Turn the printer back on, making sure that the Select button is not pressed.  
<None>

Keywords: <None>

=====  
This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 372