



Tech Info Library

ImageWriter LQ: When Top Margin Increases with Each Page

Article Created: 15 April 1991

Article Last Reviewed:

Article Last Updated:

TOPIC -----

I'm manually feeding a multi-page document through my ImageWriter LQ. The margins in Page Setup are set correctly at 1 inch, top and bottom. The paper size is correctly set to Letter, 8 1/2 x 11 inches.

The first page comes out fine, but all the other sheets' top margin increases by 1/2 inch.

DISCUSSION -----

This problem is usually caused by the Manual Feed option not being selected in the Print dialog box. The printer assumes that it should not do a backfeed, and increases the top margin on each page. (Also be sure that the DIP switch 2-8 is set to Open.)

There is something else you might try: Select the Macintosh Print dialog box by holding down the Shift key while selecting Print from the File Menu. This allows you to use the Macintosh print drivers. When you select print without holding down the Shift key, you are accessing the application's print driver.

Copyright 1991, Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 7325