



Tech Info Library

LaserWriter: Defaults

This article last reviewed: 18 July 1986

The LaserWriter picks up its default settings, such as tall orientation, from the printer driver. To bring up a document with settings different from the default, such as wide orientation, create a special "boilerplate" document with the settings you require. Once you change the defaults, the new configurations are stored with the document when you save it. This method gives you much more versatility and is much easier than using RESEDIT to change the driver.

From then on, open that same document for those printer settings; they will automatically set to those stored with the document. Then use the "Save AS" option and save the document with a new name, which will preserve the original for the creation of more documents with those special settings.

<None>

Keywords: <None>

=====
This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 1973