Tech Info Library

LaserWriter IINT Manual Feed: Why Paper-Out Light Stays Lit

Article Created: 13 February 1992
Article Last Reviewed:
Article Last Updated:

TOPIC ---

When I print from the manual-feed tray on my LaserWriter IINT, the paper-
out status light stays lit. I can still print from the tray without any
problem, but the only way I can clear the status light is to open and shut
the printer cover.

DISCUSSION --

There is a bug in the LaserWriter IINT ROM that causes this. If you have a
piece of paper in the manual-feed tray when you issue a manual-feed print
job, the status light stays on after the print cycle. The workaround is to
send the manual-feed print job, then wait until the status light is
blinking before you insert the piece of paper.

There is no other workaround for this problem, and none is planned because
it is a cosmetic problem and does not affect the actual operation of the
printer.
Copyright 1992 Apple Computer, Inc.

Keywords: <None>

==

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 9867