



Tech Info Library

LaserWriter: How to Turn Off the Test Page on Startup (10/94)

Article Created: 6 April 1989

Article Reviewed/Updated: 12 October 1994

TOPIC -----

Normally, your LaserWriter prints a test page every time you turn on its power. This is the page with a large ampersand and other printer configuration facts on it. This article describes how you can disable this test page.

DISCUSSION -----

You can inhibit the LaserWriter from printing a test page every time it's powered up.

With a Macintosh

=====

Use the LaserWriter Utility (System 7.0 or higher) and select "Set Startup Page..." from the Utilities menu. You are presented with an option to turn the Startup Page On or Off.

With an MS DOS Based System

=====

A boolean value called `dostartpage` is stored in the persistent parameters of all LaserWriters. You change this value with these PostScript programs:

Disable Startup Page PostScript Program

This program disables the printing of a start-up page:

```
serverdict begin 0 exitserver
statusdict begin false setdostartpage
```

Enable Startup Page PostScript Program

This program enables the printing of a start-up page:

```
serverdict begin 0 exitserver
statusdict begin true setdostartpage
```

These programs can be sent via a PostScript downloading program, a word processor that supports straight ASCII output (no imbedded control codes), or entered while in PostScript Interactive mode.

Article Change History:

- 12 Oct 1994 - Added keyword, reformatted, and made minor updates.
- 25 Oct 1993 - Updated to include MSDOS information
- 04 Mar 1993 - Revised to provide additional keywords and clarify the title

Support Information Services

Copyright 1989-94, Apple Computer, Inc.

Keywords: kalley

=====

This information is from the Apple Technical Information Library.

19960606 07:04:28.00

Tech Info Library Article Number: 3704