



# Tech Info Library

## LaserWriter Pro: Smudging with Duplex Printing 11/93

Article Created: 4 November 1993

TOPIC -----

When attempting duplex printing the top inch of the second side is smudged.

DISCUSSION-----

The cause of the smudging on the second side is due to the top edge paper curl that the paper gets on the first pass. This curling is due to humidity, type of paper used and the heat of fusing.

One work around is to print the second side by:

- 1) Use "Page Setup" to flip the image both vertically and horizontally
- 2) Use the Multipurpose Tray
- 3) Feed the trail edge first into the printer

By flipping the image vertically and horizontally in the "Page Setup" menu, the original trailing edge of the page is fed into the printer rather than the original leading edge.

Copyright 1993, Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 13872