



Tech Info Library

LaserWriter Pro: Indicator Lights (LEDs)

Article Created: 6 January 1993

TOPIC -----

What are the functions of the indicator lights on the side of the Apple LaserWriter Pro 600 and 630 printers?

DISCUSSION -----

The function of the LaserWriter Pro indicator lights (LEDs) is as follows:

COLOR -----	NAME -----	FUNCTION -----
GREEN	Ready/In Use	ON when the printer is ready to Print. FLASHES when the printer is not ready to print due to warm-up (WAIT status). FLASHES while the controller is preparing data for printing. OFF when the printer is not ready to print due to an error condition.
ORANGE	Low Toner Level	ON when printer status indicates that the toner cartridge is low. FLASHES when cartridge is not installed. OFF otherwise.
RED	Paper Out	ON when printer status indicates paper out in CASSETTE FEED mode. FLASHES when printer status indicates paper out in MANUAL FEED mode. OFF otherwise.

RED Paper Jam ON when printer status indicates paper jam.

OFF otherwise.

Copyright 1993, Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 11189