



# Tech Info Library

## LaserWriter Select Printers: Fuser Temperature (10/94)

Article Created: 3 October 1994

TOPIC -----

What is the fuser temperature of the LaserWriter Select 300/310/360? I am trying to use some special labels that may be damaged if the temperature exceeds 410 degrees.

DISCUSSION -----

The fusing temperatures for the LaserWriter Select printers are as follows:

LaserWriter Select 300/310

Paper Size -----	Fusing Temperature (Max) -----
A4, Letter, Legal	320°F (160°C)
Post Card, COM-10, Monarch, C5, DL	331°F (166°C)

LaserWriter Select 360

Paper Size -----	Fusing Temperature (Max) -----
A4, Letter, Legal	331°F (166°C)
Post Card, COM-10, Monarch, C5, DL	361°F (183°C)

Support Information Services  
Copyright 1994, Apple Computer, Inc

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 16430