



# Tech Info Library

## LaserWriter to PC: LaserWriter Switch Settings

Article Created: 14 June 1991

Article Last Reviewed:

Article Last Updated:

TOPIC -----

I have a serial cable that was specifically designed to connect my Apple LaserWriter IINTX to a DOS machine.

What are the switch settings on the LaserWriter that will allow my Compaq computer to transmit data serially and have PostScript access?

I want to transmit at least 9600 Baud, but not greater than 19,200 Baud.

DISCUSSION -----

Here are your LaserWriter switch settings:

For 9600, XON/XOFF handshake and PostScript:

Off On Off Off Off Off

For 9600, XON/XOff handshake and text (screen dumps, text only Applications):

Off On On Off Off Off

Copyright 1991 Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 8478