



# Tech Info Library

## Apple II Machine Language: Accessing the keyboard

When writing a machine language routine to check the keyboard for a single character, make sure that the routine checks for the high bit at the keyboard, signifying valid data, before the routine attempts to read data there.

Here is an example of such a routine:

```
ORG $300
KBD EQU $C000 ; location of keyboard data
KBDSTRB EQU $C010 ; location of keyboard strobe latch

ReadKey BIT KBD ; test high bit of data reg.
        BPL ReadKey ; If not set retest till it is set
        LDA KBD ; Data at KBD is Valid (High Bit set)
        BIT KBDSTRB ; now clear the keyboard for the next char
        RTS ; and we are done.
```

The act of striking a key will set the strobe bit automatically, so this routine clears it before returning.

If you are testing for a particular keystroke, put the test in a separate routine. Here is an example of how that would be done:

```
...
        BIT KBDSTRB ; Clear out any data that is already at KBD
WaitForA JSR ReadKey ; get a key from the keyboard
        CMP #$C1 ; is it an A????
        BNE WaitForA ; Nope go get another
        RTS
...
```

These methods apply to all Apple II's: II, II Plus, IIe, IIe enhanced, and IIc.

Apple Technical Communications

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 1986