



# Tech Info Library

## A/UX: Determining Available Memory (9/94)

Article Created: 7 September 1989

Article Reviewed/Updated: 13 September 1994

TOPIC -----

After I start up A/UX, and the splash screen is gone, how can I determine how much memory is installed in the system and how much is available? I am looking for a shell command, if it exists.

DISCUSSION -----

There is no command shipped with A/UX that will provide this information. It would be possible to write a program that returned these values, but none are included.

We don't think these values change frequently enough to require much attention. Users generally know when they change the amount of installed RAM, and the available memory only changes when the kernel is reconfigured.

A/UX 2.0: Select About the Finder in the Apple menu (while in the Finder)

A/UX 3.0: Open the Memory Control Panel for a display of both physical and virtual memory. ( Control panels can be found under the Apple menu)

### Article Change History:

13 Sep 1994 - Reviewed.

31 Aug 1992 - Updated to include A/UX 2.0 and 3.0

Support Information Services

Copyright 1989, 1992,1994 Apple Computer, Inc.

Keywords: <None>

=====  
This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 4378