



Tech Info Library

Parallel Interface Card: Product Description (11/96)

Article Created: 24 October 85

Article Reviewed/Updated: 19 November 1996

TOPIC -----

This article describes the Apple II Parallel Interface card and includes other related information.

DISCUSSION -----

DB-25 Connector Pinout

DB-25

Connector	Signal Name
-----------	-------------

- | | |
|---------|-----------------|
| 1..... | Data In, Bit 0 |
| 2..... | Signal Ground |
| 3..... | Data In, Bit 2 |
| 4..... | Signal Ground |
| 5..... | Data Out, Bit 0 |
| 6..... | Data Out, Bit 1 |
| 7..... | Blocked |
| 8..... | Data Out, Bit 2 |
| 11..... | Data Out, Bit 5 |
| 12..... | Data Out, Bit 6 |
| 13..... | Data Out, Bit 7 |
| 14..... | Data In, Bit 4 |
| 15..... | Strobe Out |
| 16..... | Acknowledge In |
| 17..... | Data In, Bit 1 |
| 18..... | Data In, Bit 7 |
| 19..... | Data In, Bit 5 |
| 20..... | Signal Ground |
| 21..... | Data In, Bit 6 |
| 22..... | Data Out, Bit 3 |
| 23..... | Data Out, Bit 4 |
| 24..... | Signal Ground |
| 25..... | Data In, Bit 3 |

Switch Settings

=====

Strobe Length

1 microsecond -> SW1-1:Off, SW1-2:Off, SW1-3:Off
3 microseconds -> SW1-1:On, SW1-2:Off, SW1-3:Off
5 microseconds -> SW1-1:Off, SW1-2:On, SW1-3:Off
7 microseconds -> SW1-1:On, SW1-2:On, SW1-3:Off
9 microseconds -> SW1-1:Off, SW1-2:Off, SW1-3:On
11 microseconds -> SW1-1:On, SW1-2:Off, SW1-3:On
13 microseconds -> SW1-1:Off, SW1-2:On, SW1-3:On
15 microseconds -> SW1-1:On, SW1-2:On, SW1-3:On

Strobe Polarity

Positive -> SW1-4:Off
Negative -> SW1-4:On

Ack Polarity

Positive -> SW1-5:Off
Negative -> SW1-5:On

Firmware Select

Parallel (LF) -> SW1-6:Off
Centronics (No LF) -> SW1-6:On

Interrupts

Disable -> SW1-7:Off
Enable -> SW1-7:On

Interrupts should be enabled for the Apple III and disabled for the Apple II.

Switch Setting Explanations

Different peripherals (non-Apple printers, etc.) may use I/O signals that have different duration and polarity. The STROBE LENGTH, STROBE POLARITY, and ACK POLARITY switch settings on the Parallel Interface Card (2PIC) give you the flexibility to communicate with these other devices. For the I/O signal characteristics of the device you are connecting with, read its manual.

Controlling Bit 8

The following program enables you to control bit 8, used by some printers to select expanded or normal print mode or to enable alternate or graphics

character sets. DOS 3.2 or DOS 3.3 is required to use this routine, which also works in the Apple III in Emulation mode.

Determine which slot your interface card is in and the corresponding slot code from the table. Replace "<slot>" with the slot number and "<code>" with the code when typing in the program.

slot	1	2	3	4	5	6	7
code	C1	C2	C3	C4	C5	C6	C7

Enter the monitor with Call -155 and type:

```
3B0:A9 <slot>
:20 95 FE
:A9 80
:20 ED FD
:A9 C5
:85 36
:A9 03
:85 37
:4C EA 03
:29 7F
:0D CD 03
:4C 02 <code>
:80
```

To check your typing, type: 3B0L

Compare your listing to the one below configured for slot 1.

```
03B0-  A9 01      LDA  #$01
03B2-  20 95 FE   JSR  $FE95
03B5-  A9 80      LDA  #$80
03B7-  20 ED FD   JSR  $FDED
03BA-  A9 C5      LDA  #$C5
03BC-  85 36      STA  $36
03BE-  A9 03      LDA  #$03
03C0-  85 37      STA  $37
03C2-  4C EA 03   JMP  $03EA
03C5-  29 7F      AND  #$7F
03C7-  0D CD 03   ORA  $03CD
03CA-  4C 02 C1   JMP  $C102
03CD-  80        ???
```

Enter 3D0G to return to Basic.

Save the driver to disk by typing: BSAVE CEN 730, A\$3B0, L\$1E

Load the driver and initialize the interface before using the printer. From command mode, type:

```
BLOAD CEN 730
Call 944
```

Or from a program: 100 Print D\$;"BLOAD CEN 730" : Call 944, assuming that D\$ is a CTRL-D.

To switch back to the video monitor for output type: PR#0
or in a program enter: 200 Print D\$;"PR#0"

To reconnect the printer, all that is required is: Call 954, or from a program:
300 Call 954

To set normal print mode, type POKE 973,0; type POKE 973,128 to set the expanded print mode POKE.

Cable Pinouts

Here is a sample pinout for an Apple II parallel card to a parallel printer.

20-Pin DIL Connector (Female)	Amphenol Connector (Male)
1 -----	14
2 -----	10
8 -----	1
10 -----	2
11 -----	3
12 -----	4
13 -----	5
14 -----	6
15 -----	7
16 -----	8
17 -----	9
20 -----	16

Article Change History:

19 Nov 1996 - Reviewed for technical accuracy, revised formatting.

Copyright 1988-96, Apple Computer, Inc.

Keywords: HTS,CNFG

=====

This information is from the Apple Technical Information Library.

19961122 07:37:55.00

Tech Info Library Article Number: 1415