



# Tech Info Library

## Apple II High-Speed SCSI Card: Setting SCSI ID (11/96)

Article Created: 18 January 1995

Article Reviewed/Updated: 15 November 1996

TOPIC -----

This article discusses how to change the Apple II High-Speed SCSI Card's SCSI ID switch settings.

DISCUSSION -----

Switch 1 turns on and off DMA (Direct Memory Access). See the article "Apple II High-Speed SCSI Card: Setting DMA" for more information on this subject.

The computer's SCSI ID number is determined by the positions of switches 2, 3, and 4 on the SCSI card. Follow these steps to reset the computer's SCSI ID number:

1. Switch the computer off, but leave the power cord plugged in.
2. Choose an appropriate SCSI ID number for the computer. If you are using a LaserWriter IISC, Personal LaserWriter SC or Apple Scanner, use the settings for SCSI ID 2.
3. Refer to the information that follows for the correct position of switches 2, 3, and 4.

Switch indication

-----							
0 = Open or off				x = Closed or on			
SCSI	SCSI	SCSI	SCSI	SCSI	SCSI	SCSI	SCSI
ID 0	ID 1	ID 2	ID 3	ID 4	ID 5	ID 6	ID 7
OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN
1234	1234	1234	1234	1234	1234	1234	1234
----	----	----	----	----	----	----	----
000	00	0 0	0	00	0	0	
x	x x	x x	x xx	xx	xx x	xxx	xxxx

4. Be sure to follow the installation instructions in the Apple II High-Speed

SCSI Card Owners Guide to install the SCSI card.

Article Change History:

15 Nov 1996 - Reviewed for technical accuracy, revised formatting.

Copyright 1995-96, Apple Computer, Inc.

Keywords: hts

=====

This information is from the Apple Technical Information Library.

19961122 07:37:55.00

Tech Info Library Article Number: 17037